

**P.I.C.S MOBILES ADAPTER LIST 02**

PART NUMBER	DESCRIPTION	NOTE	COD SITEC	NOTE	SUITABLE FOR:	
602013M001	MOBILE ADAPTER	PHILIPS	PIPH2815	-	Mobile adapter Philips Genie-Genie Sport- <b>DB-2000</b>	
602012M001	MOBILE ADAPTER	BOSCH	CIBOC003	-	Mobile adapter Bosch M-COM 506	<b>AA</b>
602090M001	MOBILE ADAPTER	MOTOROLA	CIMO1635	-	Mobile adapter Motorola 8700-8900	<b>AA</b>
602012M002	MOBILE ADAPTER	BOSCH	CIBOC004	-	Mobile adapter Bosch M-COM 607-608	
602010M002	MOBILE ADAPTER	SIEMENS	CISI2345	-	Mobile adapter Siemens S15	<b>BB</b>
602012M003	MOBILE ADAPTER	BOSCH	CIBOC005	-	Mobile adapter Bosch M-COM 718-738	<b>BB</b>
602014M001	MOBILE ADAPTER	ERICSSON	CIERC002	-	Mobile adapter Ericsson 237-238-318-337-338-388	
602014M002	MOBILE ADAPTER	ERICSSON	CIERC004	-	Mobile adapter Ericsson 628-688	<b>CC</b>
602014M003	MOBILE ADAPTER	ERICSSON	CIERC004	-	Mobile adapter Ericsson 768-738-788-788e-868-888	<b>CC</b>
602267M000	MOBILE ADAPTER	ERICSSON	CIERIT28		Mobile adapter <b>Ericsson T28s-R320 T29 T39 T65 T68</b>	
602090M002	MOBILE ADAPTER	MOTOROLA	CIMO1620	-	Mobile adapter Motorola Startac TM130	<b>DD</b>
602090M003	MOBILE ADAPTER	MOTOROLA	CIMO1617	-	Mobile adapter Motorola CD920-CD930	<b>DD</b>
602011M001	MOBILE ADAPTER	NOKIA	CINO1840	-	Mobile adapter Nokia 1610-1611-1630-1650	<b>EE</b>
602011M002	MOBILE ADAPTER	NOKIA	CINO1835	-	Mobile adapter Nokia 3110	<b>EE</b>
602011M003	MOBILE ADAPTER	NOKIA	CINO1850	-	Mobile adapter Nokia 8110-8110i	<b>EE</b>
602011M004	MOBILE ADAPTER	NOKIA	CINO1830	-	Mobile adapter Nokia 2010-2110-2110i	
602011M005	MOBILE ADAPTER	NOKIA	CINO1845	-	Mobile adapter Nokia 5110-5130	<b>FF</b>
602011M006	MOBILE ADAPTER	NOKIA	CINO1845	-	Mobile adapter Nokia 6110-6150- <b>7110</b>	<b>FF</b>
602015M001	MOBILE ADAPTER	PANASONIC	CIPA2105	-	Mobile adapter Panasonic G450-G500	
602015M002	MOBILE ADAPTER	PANASONIC	CIPA2106	-	Mobile adapter Panasonic G600	
602014M004	MOBILE ADAPTER	ERICSSON	CIER1331	-	Mobile adapter Ericsson <b>T18s T10</b>	
602017M001	MOBILE ADAPTER	SAGEM	CISG2920	-	Mobile adapter Sagem RC715-725-730-810-820 RD750R / MC810-820-850	
602010M001	MOBILE ADAPTER	SIEMENS	CISI2330	-	Mobile adapter Siemens S6	
602010M003	MOBILE ADAPTER	SIEMENS	CISI2335	-	Mobile adapter Siemens C25/ <b>S25/SL45/ME45</b>	
	MOBILE ADAPTER	SIEMENS	CISI2347	-	Mobile adapter Siemens C35/S35/M35/A35	
602268M000	MOBILE ADAPTER	NEC			Mobile adapter <b>Nec DB2000</b>	
602269M000	MOBILE ADAPTER	PANASONIC			Mobile adapter Panasonic <b>GD30/50/70/90</b>	
602270M000	MOBILE ADAPTER	NOKIA	CINO1848		Mobile adapter Nokia <b>3210-8210-8850-3310-3330</b>	
602272M001	MOBILE ADAPTER	SAMSUNG			Mobile adapter Samsung <b>SGH2200-2400</b>	
602272M000	MOBILE ADAPTER	MOTOROLA			Mobile adapter Motorola <b>V3688 L7089 P7389 V3690</b> time port serie.	
602273M000	MOBILE ADAPTER	ALCATEL			Mobile adapter Alcatel <b>ONE TOUCH DB serie</b>	
602271M001	MOBILE ADAPTER	SAMSUNG			Mobile adapter Samsung <b>SGH600</b>	
600796M	INTERFONO		CIINTSIT	-		

**Note: MODEL WITH THE SAME LETTER IN THE LAST COLUMN ARE INTERCHANGEABLE (e.g. AA,EE etc)**