

## P.I.C.S MOBILES ADAPTER LIST

PART NUMBER	DESCRIPTION	MODEL	NOTES	SUITABLE FOR:	
602273M000	MOBILE ADAPTER	ALCATEL		- Alcatel ONE TOUCH DB serie	
602012M001	MOBILE ADAPTER	BOSCH	Inserire da spento	- Bosch M-COM 506	AA
602012M002	MOBILE ADAPTER	BOSCH		- Bosch M-COM 607-608	
602012M003	MOBILE ADAPTER	BOSCH		- Bosch M-COM 718-738	BB
602014M001	MOBILE ADAPTER	ERICSSON		- Ericsson 237-238-318-337-338-388	
602014M002	MOBILE ADAPTER	ERICSSON		- Ericsson 628-688	CC
602014M003	MOBILE ADAPTER	ERICSSON		- Ericsson 768-738-788-788e-868-888	CC
602267M000	MOBILE ADAPTER	ERICSSON		- Ericsson T28s-R320 T29 T39 T65 T68	
602014M004	MOBILE ADAPTER	ERICSSON		- Ericsson T18s T10	
602090M001	MOBILE ADAPTER	MOTOROLA	Inserire da spento	- Motorola 8700-8900	AA
602090M002	MOBILE ADAPTER	MOTOROLA	Inserire da spento	- Motorola Startac TM130	DD
602090M003	MOBILE ADAPTER	MOTOROLA	Usare solo a tel accesso	- Motorola CD920-CD930	DD
602272M000	MOBILE ADAPTER	MOTOROLA	T720 tono pics/happy dopo La suonera	- Motorola V3688-L7089 P7389-V3690- V50-V51-T191-T192-V60-V66-V70-T720 time port serie.	
602268M000	MOBILE ADAPTER	NEC		- Nec DB2000	
602011M001	MOBILE ADAPTER	NOKIA		- Nokia 1610-1611-1630-1650	EE
602011M002	MOBILE ADAPTER	NOKIA		- Nokia 3110	EE
602011M003	MOBILE ADAPTER	NOKIA		- Nokia 8110-8110i	EE
602011M004	MOBILE ADAPTER	NOKIA		- Nokia 2010-2110-2110i	
602011M005	MOBILE ADAPTER	NOKIA		- Nokia 5110-5130	FF
602011M006	MOBILE ADAPTER	NOKIA		- Nokia 6110-6150-7110-6210	FF
602270M000	MOBILE ADAPTER	NOKIA		- Nokia 3210-8210-8850-3310-3330-3410- 3510-6510-8310-8910	
602678M002	MOBILE ADAPTOR	NOKIA		- Nokia 6310	
602015M001	MOBILE ADAPTER	PANASONIC		- Panasonic G450-G500	
602015M002	MOBILE ADAPTER	PANASONIC		- Panasonic G600	
602269M000	MOBILE ADAPTER	PANASONIC		- Panasonic GD30/50/70/90	
602013M001	MOBILE ADAPTER	PHILIPS		- Philips Genie-Genie Sport-DB-2000	
602017M001	MOBILE ADAPTER	SAGEM		- Sagem RC715-725-730-810-820 RD750R / MC810-820-850	
602271M001	MOBILE ADAPTER	SAMSUNG	Riposta conTasto	- Samsung SGH600	
602272M001	MOBILE ADAPTER	SAMSUNG		- Samsung SGH2200-2400	
602010M002	MOBILE ADAPTER	SIEMENS		- Siemens S15	BB
602010M001	MOBILE ADAPTER	SIEMENS		- Siemens S6	
602010M003	MOBILE ADAPTER	SIEMENS		- Siemens C25/S25/SL45/ME45	
	MOBILE ADAPTER	SIEMENS		- Siemens C35/S35/M35/A35	
602678M001	MOBILE ADAPTOR	SIEMENS	Riposta conTasto apri	- Siemens M30-C30	
602678M000	MOBILE ADAPTOR	SONY	Risp autom. Autom predef	- Sony CMD Z5-CD5	

Note: MODEL WITH THE SAME LETTER IN THE LAST COLUMN ARE INTERCHANGEABLE (e.g. AA,EE etc)